

Seat Belt Panel (Belt Guidance System) for Front Seat (8-way, 16-way electric)





- 1. Remove seat belt panel (belt guidance system) from front seat Note: The front seat need not be removed in order to remove the panel.
 - Detach seat belt panel (belt guidance system) (1) from front seat and remove.





- 2. Install seat belt panel (belt guidance system) (1) at front seat
 - Slide in seat belt panel (belt guidance system) at front seat Note: Ensure correct belt guidance of front seat belt (2).